



Made in America Since 1968

# RENTAL IN/OUT CHECKLIST

## 8000

8000-HER, 8000-SUN

Each time the 8000 is rented out and returned, follow these steps to ensure it is in proper working condition.

Before conducting any maintenance procedures, make sure you are wearing proper safety equipment and the machine is disconnected from power.

*\*Refer to [Service Manual](#) for precise schedule*



- Read the manual before operating the machine.
- Inspect the air filter.
- Check for propane, oil, coolant, and hydraulic fluid.
- Check engine oil level.
- When unit is cold, check coolant level.
- Check propane tank fuel level.
- Check fan belt tension and condition.
- Ensure the seat is securely fastened to the machine. The seat has a safety switch. The operator must be properly seated for the machine to run.
- Sit on the machine, follow start procedure and verify machine runs. (See manual for start procedure)
- With the machine off, make certain the control levers are working properly and return freely to the center position when not being engaged by the operator.
- Check that the backup beeper is working.
- Check hydraulic fluid level.
  - Remove filler plug located in front of right, rear tire.
  - Hydraulic fluid should be visible 1" below hole.
  - Reinsert filler plug.
- Keep fittings and hoses tight. If a leak is noticeable, re-tighten fitting. If leakage persists, remove the connection and inspect. **Caution:** Never check for hydraulic leaks while machine is running.
- Remove any glue, mastic, and debris from the wheels, debris deflector, and cutting head.
- Look for damage to the cutting head.
- Check battery cables for corrosion and make sure they are secure.
- Check battery condition.
- All maintenance, nameplates and safety stickers must be visible.



**SCAN TO ACCESS YOUR MANUAL**