



Made in America Since 1968

MAINTENANCE CHECKLIST

GP500

Before conducting any maintenance procedures, make sure you are wearing proper safety equipment and the machine is disconnected from power.

**Refer to [Service Manual](#) for precise schedule*



- Ensure water tank is empty and clean
- Safety emergency stop button is functioning
- Two removable weights on grinder base are present
- Check control box: start, forward/reverse and variable speed functionality
- Check skirt condition
- Ensure rubber couplers are free of damage
- Ensure dust collector hose from grinder base to dust collector port is hooked up and free of damage
- Check frame and base for cracks or visible damage
- With water in the tank, turn water trickle knob to make sure water is being released onto the diamond tooling



**SCAN TO
ACCESS
YOUR
MANUAL**